

INON

INON UFL-M150 ZM80 Compatibility Chart

This chart provides necessary information when you use 「UFL-M150 ZM80」 for your camera system. Please make sure to check compatibility, necessary Mount Base and Mount Converter before using this product.

Glossary: “Comp.” Compatibility of the UFL-M150 ZM80. “O” : compatible. “X”: Not compatible
 “M.B.” Compatible Mount Base type to use the UFL-M150 ZM80.
 “M.C.” Indicates necessary Mount Converter to attach the UFL-M150 ZM80 on a Mount Base.
 M27-AD means 「M27-AD Mount Converter for UFL-M150 ZM80」
 M27-LD means 「M27-LD Mount Converter for UFL-M150 ZM80」
 M27-M67 means 「M27-M67 Mount Converter for UFL-M150 ZM80」

Compatibility Chart

Mfr.	Housing	Camera	Comp.	M.B.	M.C.	RMK	
Olympus	PT-056	TG-3	O		M27-M67	*3	
	PT-055	TG-830,TG-835	O		M27-M67	*3	
	PT-054	XZ-2	x			*1	
	PT-053	TG-1,TG-2	O		M27-M67	*3	
	PT-052	TG-820	O		M27-M67	*3	
	PT-051	TG-610, TG-615, TG-810	O		M27-M67	*3	
	PT-050	XZ-1	x			*1	
	PT-047	μ TOUGH-6000	O	28AD Mount Base·PT-045/047	M27-AD		
	PT-046	FE-3010	O	AD Mount Base·PT-046	M27-AD		
	PT-045	μ TOUGH-8000	O	28AD Mount Base·PT-045/047	M27-AD		
	PT-044	FE-360	O	AD Mount Base·PT-044/046	M27-AD		
	PT-043	μ1030SW	O	28AD Mount Base·PT-043	M27-AD		
	PT-042	μ1020	x			*2	
	PT-041	μ790SW,μ850SW	O	AD Mount Base·PT-041	M27-AD		
	PT-039	μ780,μ830	untested				
	PT-037	SP-550UZ/560UZ	x			*1	
	PT-036	μ760	O	AD Mount Base·PT-032/036	M27-AD		
	PT-035	μ770SW,μ795SW	O	AD Mount Base·PT-033/035	M27-AD		
	PT-034	μ750	untested				
	PT-033	μ720SW,μ725SW	O	AD Mount Base·PT-033/035	M27-AD		
	PT-032	μ710	O	AD Mount Base·PT-032/036	M27-AD		
	PT-031	SP-700	O	AD Mount Base·PT-031	M27-AD		
	PT-030	SP-350	O	AD Mount Base·PT-030	M27-AD		
	PT-029	μ600	O	AD Mount Base·PT-029	M27-AD		
	PT-027	C-7070WZ	x			*1	
	PT-026	μ-40	O	AD Mount Base·PT-026	M27-AD		
	PT-024	X-3	O	AD Mount Base·PT-024	M27-AD		
	PT-023	C-8080WZ	x			*1	
	PT-022	C-760UZ,C-770UZ	x			*1	
	PT-020	C-5060WZ	x			*1	
	PT-018	C-740UZ,C-745UZ,C-750UZ,C-755UZ	x			*1	
	PT-016	μ-10,μ-15,μ-20 μ-25,μ-30	O	AD Mount Base·PT-016	M27-AD		
	PT-015	C-5050Z	x			*1	
PT-014	X-1,X-2	O	AD Mount Base·PT-014 M67 Mount Base·PT-014	M27-AD M27-M67			
PT-012	C-40Z	O	AD Mount Base·PT-012 M67 Mount Base·PT-012	M27-AD M27-M67			
PT-010	C-2020Z,C-2040Z,C-3000Z, C-3030Z,C-3040Z,C-3100Z, C-4040Z,C-4100Z	x			*1		
PT-009	C-200Z,C-300Z	untested					
Fujifilm	WP-XQ1	XQ1	O	28LD Mount Base·XQ1	M27-LD		
	WP-FXF500	Finepix F300EXR, F550EXR, F600EXR	x			*1	
	WP-FXF80	Finepix F80EXR	x			*1	
	WP-FXF200	Finepix F200EXR	x			*1	
	WP-FXF100	Finepix F100fd	x			*1	
	WP-FXF50	Finepix F50fd	O	AD Mount Base·FXF50	M27-AD		
	WP-FXF40	Finepix F40fd	O	AD Mount Base·FXF40	M27-AD		
	WP-FXF30	Finepix F30,F31fd	O	AD Mount Base·FXF30	M27-AD		
	WP-FXF10	Finepix F10,F11	O	AD Mount Base·FXF10	M27-AD		
	Sony	MPK-WH	DSC-WX200,WX100 DSC-WX50	x			*2
MPK-THGB		DSC-T90,T77,T700	O	AD Mount Base·THG/THGB	M27-AD		
MPK-THG		DSC-T77,T700	O	AD Mount Base·THG/THGB	M27-AD		
MPK-WD		DSC-W300 DSC-W170	O	M67 Mount Base·WD	M27-M67		
MPK-WA		DSC-W1,W5,W7	O	AD Mount Base·WA	M27-AD		
MPK-NA		DSC-N1,N2	O	AD Mount Base·NA	M27-AD		
MPK-PHB		DSC-P100,P150	O	AD Mount Base·PHB	M27-AD		
Canon		WP-DC36	IXY 200F	O	28AD Mount Base·DC36	M27-AD	
		WP-DC33	IXY D220IS	O	28AD Mount Base·DC33	M27-AD	
		WP-DC32	IXY D510IS	O	28AD Mount Base·DC32	M27-AD	
	WP-DC31	IXY D210IS	O	AD Mount Base·DC31	M27-AD		
	WP-DC29	IXY D110IS	O	AD Mount Base·DC29	M27-AD		
	WP-DC27	IXY D3000IS	O	AD Mount Base·DC19/27	M27-AD		
	WP-DC26	IXY D920IS	O	28AD Mount Base·DC26	M27-AD		
	WP-DC24	IXY D95IS	O	AD Mount Base·DC22/23/24	M27-AD		
	WP-DC23	IXY D25IS	O	AD Mount Base·DC22/23/24	M27-AD		
	WP-DC22	IXY D20IS	O	AD Mount Base·DC22/23/24	M27-AD		
	WP-DC19	IXY D2000IS	O	AD Mount Base·DC19/27	M27-AD		
	WP-DC17	IXY D910IS	O	28AD Mount Base·DC17	M27-AD		
	WP-DC15	IXY D810IS	O	AD Mount Base·DC5/15	M27-AD		
	WP-DC14	IXY D90	O	AD Mount Base·DC3/4/13/14	M27-AD		
	WP-DC13	IXY D10	O	AD Mount Base·DC3/4/13/14	M27-AD		
	WP-DC9	IXY D900IS	O	28AD Mount Base·DC9	M27-AD		
	WP-DC7	IXY D1000	O	AD Mount Base·DC7	M27-AD		
	WP-DC5	IXY D800IS	O	AD Mount Base·DC5/15	M27-AD		
	WP-DC4	IXY D70	O	AD Mount Base·DC3/4/13/14	M27-AD		
	WP-DC3	IXY D80	O	AD Mount Base·DC3/4/13/14	M27-AD		
WP-DC0	IXY D700	O	AD Mount Base·DC70/80	M27-AD			
WP-DC07	IXY D600	O	AD Mount Base·DC70/80	M27-AD			
WP-DC800	IXY D400/D450/D500	O	AD Mount Base·DC800	M27-AD			
WP-DC52	PowerShot G16	x			*1		
WP-DC51	PowerShot S120	O	28LD Mount Base·DC51	M27-LD			
WP-DC49	PowerShot SX280HS	x			*1		
WP-DC48	PowerShot G15	x			*1		
WP-DC47	PowerShot S110	O	28LD Mount Base·DC43/47	M27-LD			
WP-DC46	PowerShot SX260HS	x			*1		
WP-DC45	PowerShot D20	x			*2		
WP-DC44	PowerShot G1X	x			*1		
WP-DC43	PowerShot S100	O	28LD Mount Base·DC43/47	M27-LD			
WP-DC38	PowerShot S95	O	28LD Mount Base·DC38	M27-LD			
WP-DC35	PowerShot S90	O	28AD Mount Base·DC35	M27-AD			
WP-DC12	PowerShot A570IS	O	AD Mount Base·DC12	M27-AD			
WP-DC2	PowerShot A540	O	AD Mount Base·DC2	M27-AD			
WP-DC1	PowerShot S80	O	28AD Mount Base·DC1	M27-AD			
Panasonic	MCFT5	LUMIX FT5	O	28LD Mount Base·FT5	M27-LD		
	MCFT3	LUMIX FT3, FT4	O	28LD Mount Base·FT3	M27-LD		
	MCFT2	LUMIX FT2	O	28AD Mount Base·FT2	M27-AD		
	MCFT1	LUMIX FT1	O	28AD Mount Base·FT1	M27-AD		
	MCTZ40	LUMIX TZ40	x			*1	
	MCTZ35	LUMIX TZ35	x			*1	
	MCTZ30	LUMIX TZ30	x			*1	
	MCTZ20	LUMIX TZ20	x			*1	
	MCTZ10	LUMIX TZ10	x			*1	
	MCTZ7	LUMIX TZ7	x			*1	
MCTZ5	LUMIX TZ5	x			*1		
MCZX3	LUMIX ZX3,ZX1	x			*1		
MCZX1	LUMIX ZX1	x			*1		
MCFX40	LUMIX FX40	O	28AD Mount Base·MCFX5/FX35/FX40	M27-AD			
MCFX35	LUMIX FX37,FX35	O	28AD Mount Base·MCFX5/FX35/FX40	M27-AD			
MCFX30	LUMIX FX33,FX30	O	28AD Mount Base·MCFX01/07/30	M27-AD			
MCFX07	LUMIX	O	28AD Mount Base·MCFX01/07/30	M27-AD			
MCFX01	LUMIX FX01	O	28AD Mount Base·MCFX01/07/30	M27-AD			
MCFX5	LUMIX FS3	O	28AD Mount Base·MCFX5/FX35/FX40	M27-AD			
Nikon	WP-N3	Nikon 1 J4	O		M27-M67		
	WP-N2	Nikon 1 J3	O		M27-M67		
	WP-N1	Nikon 1 J2	O		M27-M67		

*1 Not usable since the camera has large master lens or super zoom.

*2 Not usable since image quality is extremely poor.

*3 Olympus step up ring 「PSUR-03」 is required.

INON Inc.

2-18-9, Dai, Kamakura,
 Kanagawa 247-0061 JAPAN
 E-mail support@inon.co.jp
 Fax. +81(0)467-48-2178
 URL <http://www.inon.jp/>

October 2014