

● **X-2~Lens Compatibility Chart (current lens)**

Canon wide lens	Compatible Port / Ext. Ring	Compatible Gear / Magnet Ring [*1]
EF14mm F2.8L USM	Dome Port II・Protector II Set + MF Ext.Ring M (without Control Ring) [*2]	Focus Gear 20-100
EF15mm F2.8 Fish-eye	Dome Port II・Protector II Set	Focus Gear 15-50
EF20mm F2.8 USM	Dome Port II・Protector II Set + MF Ext.Ring M (without Control Ring) [*2][*3] MF Wide Port (without Control Ring) [*2]	Focus Gear 20-100
EF24mm F2.8	MF Flat Port (without Control Ring)	Focus Gear 15-50
EF28mm F2.8 [*2]		
EF35mm F2		
Canon Macro Lens		
EF50mm F2.5 Compact Macro	MF Standard Port II (without Control Ring)	Focus Gear 15-50
EF-S60mm F2.8 Macro USM [*4]	MRS 60 Port	Magnet Ring・60 Set
	MRS 60 Port (without Control Ring) [*5]	(N/A)
EF100mm F2.8 Macro USM	MRS 100 Port・Type U II	Magnet Ring
	MRS 100 Port・Type U II (without Control Ring) [*5]	(N/A)
EF180mm F3.5L Macro USM	MRS 100 Port・Type S	Magnet Ring
	+ Ext.Ring M	(N/A)
	MRS 100 Port・Type S (without Control Ring) [*6] + Ext.Ring M	
Canon Zoom Lens		
EF-S18-55mm F3.5-5.6 II USM [*4]	MF Standard Port II (without Control Ring) [*4][*7]	Zoom Gear 18-55 II
EF-S18-55mm F3.5-5.6 IS [*4]	MF Wide Port (without Control Ring) [*2]	Focus Gear 20-100 [*8]
EF20-35mm F3.5-4.5 USM		
Tokina Zoom Lens		
AT-X107DX Fish-eye [*4]	Dome Port II・Protector II Set + Ext.Ring S (+ Shade Sponge AT-X107 [*9])	Zoom Gear AT-X107

● **X-2~ Lens Compatibility Chart (discontinued lens)**

Canon Macro Lens	Compatible Port /Ext.Ring	Compatible Gear/Magnet Ring [*1]
EF100mm F2.8 Macro [*10]	MRS 100 Port・Type S	Magnet Ring・100S Set
	MRS 100 Port・Type S (without Control Ring) [*6]	(N/A)
Canon Zoom Lens		
EF22-55mm F4-5.6 USM	MF Wide Port (without Control Ring)	Zoom Gear 28-90 USM
EF28-80mm F3.5-5.6 USM II	MF Standard Port II (without Control Ring)	
EF28-80mm F3.5-5.6 USM III		
EF28-80mm F3.5-5.6 USM IV		
EF28-80mm F3.5-5.6 USM V		
EF28-90mm F3.5-5.6 USM		
EF35-80mm F4-5.6 USM		

● **X-2~Teleconverter/Extender Compatibility Chart (current teleconverter/extender)**

Kenko Teleconverter	Compatible Lens	Compatible Ext.Ring
1.5x TELEPLUS MC4 DG for Canon EOS	EF100mm F2.8Macro [*10]	Ext.Ring 18 Kenko 1.5×
	EF100mm F2.8Macro USM	
	EF180mm F3.5LMacro USM	
2.0x TELEPLUS MC7 DG for Canon EOS	EF100mm F2.8Macro [*10]	Ext.Ring 36 Kenko 2×
	EF100mm F2.8Macro USM	
	EF180mm F3.5LMacro USM	
3.0x TELEPLUS PRO300 3XM for Canon EOS	EF100mm F2.8Macro [*10]	Ext.Ring L
	EF100mm F2.8Macro USM	
	EF180mm F3.5LMacro USM	
Canon Extender		
EXTENDER EF1.4× II	EF180mm F3.5L Macro USM	Ext.Ring 58 Canon 1.4×

● **X-2~Teleconverter/Extender Compatible Chart (discontinued teleconverter/extender)**

Kenko Teleconverter	Compatible Lens	Compatible Ext.Ring
1.5x TELEPLUS SHQ for Canon EOS	EF100mm F2.8Macro [*10]	Ext.Ring 18 Kenko 1.5×
	EF100mm F2.8Macro USM	
	EF180mm F3.5LMacro USM	
	EF100mm F2.8Macro [*10]	
2.0x TELEPLUS MC7 for Canon EOS	EF100mm F2.8Macro USM	Ext.Ring 36 Kenko 2×
	EF100mm F2.8Macro USM	
	EF180mm F3.5LMacro USM	
Canon Extender		
EXTENDER EF1.4×	EF180mm F3.5L Macro USM	Ext.Ring 58 Canon 1.4×
EXTENDER EF2×	EF180mm F3.5L Macro USM	Ext.Ring 81 Canon 2×

[*1] Necessary for single focus lens to exercise manual focusing and for zoom lens to change zoom position.
Auto focusing only when using zoom lens.
[*2] Use smaller aperture setting to avoid possible deterioration of image quality on image corners with open aperture.
[*3] Close-up lens No.2 like 「Canon Close-up Lens 500D/72mm」etc is recommended to use together to compensate longer minimum shooting distance.
in this case, infinity shooting is not available.
[*4] Not useable with EF-S lens non compatible 「EOS10D」/「X-2 for EOS10D」.
[*5] Auto focusing only. Optional 「MRSControl Magnet Ring (60/100U II)」 and compatible "Magnet Ring" is necessary for manual focusing.
[*6] Auto focusing only. Optional 「MRSControl Magnet Ring (100S/100U)」 and compatible "Magnet Ring" is necessary for manual focusing.
[*7] Use smaller aperture setting to avoid possible deterioration of image quality on image corners with open aperture at zoom wide end.
[*8] For zooming control. Auto focusing only.
[*9] Attached inside of EXT. Ring S to prevent built-in flash light from exposing in an image.
「Zoom Gear AT-X107」 includes this sponge. Necessary to purchase this sponge separately if you do not have the zoom gear.
[*10] Non USM type.

***** 「MF Port」series (「MF Standard Port II」/「MF Wide Port」/「MF Flat Port」) and 「MF Ext.Ring M」 can not be attached on「Ext.Ring」other than 「MF Ext.Ring M」